




Assembly Instructions



CONTENTS









1. Assembly Advice	Page 1
2. Product Features	Page 1 - 3
3. Parts List	Page 4 - 6
4. Overview of Doors	Page 7
Overview of Front Wall	Page 8
Overview of Rear Wall	Page 9
Overview of Sides and Roof	Page 10
Overview of EXT. 2 Section	Page 11
5. Roof Vent Assembly	Page 12 - 15
6. Door Assembly	Page 16 - 19
7. Base Assembly	Page 20 - 22
8. Framework Assembly	Page 23 - 34
9. Glazing	Page 35 - 43

Item No. & Packing List

Item No.	Product Size (LxWxH)	Packing List			
		Basic 4 Section		EXT. 2 Section	
		AL NO.1	PC/Glass NO.1	AL NO.2	PC/Glass NO.2
GM34304	257x191x218CM	1CTN	1CTN		
GM34306	380x191x218CM	1CTN	1CTN	1CTN	1CTN
GM34308	504x191x218CM	1CTN	1CTN	2CTN	2CTN
GM34310	627x191x218CM	1CTN	1CTN	3CTN	3CTN
etc.		etc.	etc.	etc.	etc.

Assembly and Maintenance Advice

1. For safety purposes, we strongly recommend that this product is assembled by at least two people.
2. Some components have sharp metal edges. Please be careful when handling metal components. Please wear gloves, shoes and safety goggles during assembly.
3. Lay all of the components on a soft carpet or blanket to avoid any scratches or damages.
4. DO NOT climb or stand on the roof. Heavy articles should not be leaned against the greenhouse.
5. Keep the roof and gutter clear of snow, dirt & leaves. Allowing snow to build up on the roof may damage the product.
6. Unlike steel, if the paint finish is scratched this will not harm the aluminium underneath.
7. When your product needs cleaning, use a mild detergent solution and rinse with cold clean water. Do not use acetone, abrasive cleaners or strong detergents to clean the panels.




Functions and Features:

1. Compared with traditional greenhouses this exciting new product features many significant improvements. The hollow box profile aluminium framing is much stronger than other greenhouses and it can withstand much greater pressure.




2. A great improvement for this new greenhouse is bar capping which is a neater and stronger way to retain the glazing. Another benefit is that these greenhouses can be glazed with glass or polycarbonate of varying thicknesses.




* If you are glazing this greenhouse with glass you will need to slide the rubber gaskets into the bar capping.

3. Base anchor brackets are included as standard with expanding bolts to ensure a secure fixing into concrete or paving. Alternatively, you can use the brackets to fix into a timber base with wood screws (not provided).




Expansion bolt
in concrete




Steel bar/Lawn land


4. Our unique frame connectors make much stronger joints than conventional greenhouses.
5. The strong two part eaves beam includes an integral gutter. Downpipes are also included as standard so you can collect rainwater.



6. Manual window handles are included as standard with the roof vents. If required, automatic roof vent openers are available as an inexpensive optional extra.




Manual Opener





Automatic Opener



7. Remove approximately 2 inches of film from all sheet edges before installing and remove all film immediately after the construction is completed. Please ensure that the side with the white film faces outwards.



8. This product can be extended freely. We have basic 4 sections and EXT. 2 sections. So, it can be extended to 6 sections or 8 or longer.



























































































9. Decorative crestings are available as an optional extra. Each 2' wide glazing panel in the sides and roof requires one set. One set includes 3xB01, 2xB02, 2xB03 and 1xL26.













Attention: Framework for whole greenhouse needs to be completed before installing polycarbonate sheet/glass.


GM34304(ALU.Box No.1)

	PART	NO	QTY		PART	NO	QTY		PART	NO	QTY		PART	NEW	OLD	QTY
1		L01A	2	10		L16A	4	1		L06B	1			A26	A	6
		L01B	2			L16B	4	2		L07B	2			A27	B	8
2		L01C	2	11		L17	1	3		L08C	2			A28	C	4
		L01D	2	12		L18A	2			L09B	2			H18	D	2
		L03C	1	13		L18D	2	4		L02A	6			J09	J01	2
3		L03D	1	14		L21C	4	5		L02B	6			J10R/LJ02R/L	2/2	
		L03E	1			L21D	4			L04A	2			J12R/LJ03R/L	1/1	
		L03F	1			L15A	2	6		L11C	8			J11	J04	4
4		L04A	5	15		L21A	4			L12G	2			J94	J05	4
5		L05A	4			L21B	4	7		L05C	8			J93	J07	4
		L05B	1	16		L19A	4			L05D	4			J92	J08	4
6		L11A	8	17		L19B	2	8		L22	9			D17	W01	6
		L11B	8	18		L20	2	9		L22D	2			D07	W05	13
		L11C	3					10		L12A	6			A01	W06	2
7		L11D	2							L12B	6			A03	W08	2
		L12G	5					11		L30/J06	4			D28	W09	2
8		L12C	2											H20	W22	2
		L12D	2											S08	S03	13
9		L08B	1											S11	S04	5
		L10	1											S14	S01	150
		L11E	1											M03	M01	155
		L13	1											M6		
		L14	1											S12	S02	2
		L23	1											M8X30		
														M06	M02	2
														M8		
														Z22	Z01	203
														Ø4X16		
														Z02	Z02	28
														Ø4X16D		
														Z04	Z03	5
														Ø4X8		
														Z12	Z04	5
														Ø4X50		




GM34304(PC/GLASS No.1)



	Y1	2
	Y2	5
	Y3	1
	Y4	2
	Y5	1
	Y6	8
	Y7	6
	Y9	2
	Y10	2
	Y11	2

PART	NO	QTY
	J60	84M




































Rubber for walls & roof
(Provided for glass only)


PART	NO	QTY
	J60	102M

Rubber for walls only
(Provided for glass only)
















EXT. 2 Sections(AU.Box No.2)

	PART	NO	QTY			PART	NO	QTY			PART	NEW	OLD	QTY
1		L06	1									A01	W06	2
2		L07	2									D24	W02	2
		L08A	2									D25	W03	2
3		L09	2									D27	W04	3
		L02A	2									D26	W07	1
4		L02B	2									D07	W05	4
		L04A	2									A03	W08	2
		L11C	4									D28	W09	2
		L12G	2									S08	S03	4
		L05C	4									S11	S04	9
6		L05D	2									S14	S01	92
		L22	3									M03	M01	101
8		L22A	2									Z22	Z01	65
9		L22C	6									A27	B	8
		L12A	4									Z02	Z02	9
10		L12B	4									Z04	Z03	5
		L03A	2									Z24	Z05	2
11		L03B	2											




EXT. 2 Sections(PC/GLASS No.2)


	Y6	4		
	Y7	2		
	Y9	2		
	Y10	2		




















PART	NO	QTY
	J60	26M

Rubber for walls & roof
(Provided for glass only)

PART	NO	QTY
	J60	36M

Rubber for walls only
(Provided for glass only)




PART	NO	QTY	PART	NO	QTY	PART	NO	QTY
	L14	1		A28	4		Y11	2
	L16A	4		H18	2			
	L16B	4		J12R/L	1/1			
	L17	1		S14 M6X10	3			
	L18A	2		M03 M6	3			
	L18D	2		S12 M8X30	2			
	L21C	4		M06 M8	2			
	L21D	4		Z22 Ø4X16	16			
				Z02 Ø4X16D	6			
				Z12 Ø4X50	4			










































Door Assembly

Overview


Frames




Aluminium Capping

PART	NO	QTY	PART	NO	QTY	PART	NO	QTY
	L01A	1		A26	3		Y1	1
	L01B	1		J09	1		Y2	2
	L01C	1		J10R/L	1/1		Y4	1
	L01D	1		J11	2		Y5	1
	L03E	1		J94	2	<div> <h1>Front Wall Assembly</h1> <h2>Overview</h2> </div>		
	L03F	1		L30	2			
	L04A	2		J93	2			
	L05A	2		J92	2			
	L10	1		D17	3			
	L11A	4		D07	2			
	L11B	4		S08	2			
	L11D	2		M8X60	28			
	L11E	1		S14	28			
	L12C	1		M6X10	28			
	L12D	1		M03	46			
	L12G	2		M6	6			
	L23	1		Z22				
				Ø4X16				
				Z02				
				Ø4X16D				


Aluminium Capping





































Panels




Frames




PART	NO	QTY	PART	NO	QTY	PART	NO	QTY	
	L01A	1		A26	3		Y1	1	
	L01B	1		J09	1		Y2	3	
	L01C	1		J10R/L	1/1		Y4	1	
	L01D	1		J11	2		Y3	1	
	L03C	1		J94	2		Y10	1	
	L03D	1		L30	2	<div>Rea</div>			
	L04A	3		J93	2				
	L05A	2		J92	2				
	L05B	1		D17	3				
	L08B	1		D07	3				
	L11A	4		S08	3				
				M8X60					
	L11B	4		S14	30				
				M6X10					
	L11C	3		M03	30				
				M6					
	L12C	1		Z22	48				
				Ø4X16					
	L12D	1		Z02	6				
				Ø4X16D					
	L12G	3							
	L13	1							


Aluminium Capping














































Panels





Frames





















































PART	NO	QTY	PART	NO	QTY
	L06B	1		Y6	6
	L07B	2		Y7	4
	L08C	2		Y9	2
	L09B	2		Y10	2
	L02A	6			
	L02B	6			
	L04A	2			
	L05C	8			
	L05D	4			
	L22	9			
	L22D	2			
	L11C	8			
	L12A	6			
	L12B	6			
	L12G	2			
	L15A	2			
	L19A	4			
	L19B	2			
	L20	2			
	L21A	4			
	L21B	4			
	A27	8			
	D07	8			
	A03	2			
	D28	2			
	S08	8			
	M8X60				
	S11	4			
	M6X20				
	S14	86			
	M6X10				
	M03	90			
	M6				
	Z22	88			
	Ø4X16				
	Z02	8			
	Ø4X16D				
	Z04	4			
	Ø4X8				

Sides and Roof Assembly



Overview of Sides and Roof



PART	NO	QTY	PART	NO	QTY	PART	NO	QTY
	L06	1		A27	8		Y6	4
	L07	2		D24	2		Y7	2
	L08A	2		D25	2		Y9	2
	L09	2		D27	3		Y10	2
	L02A	2		D07	4			
	L02B	2		A01	2			
	L04A	2		D26	1			
	L05C	4		A03	2			
	L05D	2		D28	2			
	L22	3		S14	92			
	L22A	2		M03				
	L22C	6		S08	4			
	L11C	4		M6				
	L12A	4		Z22	62			
	L12B	4		Ø4X16				
	L12G	2		Z02	8			
	L03A	2		Ø4X16D				
	L03B	2		Z04	4			
	L15A	2		Ø4X8				
	L19A	4		Z24	2			
	L19B	2		M5X25				
	L20	2						
	L21A	4						
	L21B	4						
	L27	1						
















EXT. 2 Sections Assembly

Overview of Sides and Roof




Middle Section Assembly Instruction connects greenhouse to extension.




+ EXT. 2 Sections

PART	NO	QTY	PART	NO	QTY	PART	NO	QTY
	L15A	1		A27	4		Y10	1
	L19A	2		Z22	8			
	L19B	1		Z02	4			
	L20	1		Z04				
	L21A	2		Z04	2			
	L21B	2		Z04				
	A01	1		Z04	2			


Roof Vent Assembly

Overview







After connector A27 has been fitted, use the hole in the profile to tighten the connector in place.




Push down the button on connector A27 before inserting it into the end of the frame profile.




First the glazing panel Y10 should be loosely retained by the bar capping profiles L21A and L21B. Next tap the bar capping gently into position with a rubber mallet, then fix the bar capping securely with Z22 screws.





















Install the Z02 screws to prevent the L15A from sliding off the vent.



Fix the A01 vent handles using Z04 screws.
If required, automatic vent openers can be installed
once the greenhouse is complete.




Fill silicone sealant all around Y10 and the gaps between the aluminium frames to avoid
any water leaking


PART	NO	QTY	PART	NO	QTY	PART	NO	QTY
	L14	1		A28	4		Y11	2
	L16A	4		H18	2		H20	2
	L16B	4		J12R/L	1/1			
	L17	1		S14 M6X10	3			
	L18A	2		M03 M6	3			
	L18D	2		S12 M8X30	2			
	L21C	4		M06 M8	2			
	L21D	4		Z22 Ø4X16	16			
				Z02 Ø4X16D	6			
				Z12 Ø4X50	4			

Door Assembly



Overview




Slide L16A into L17A and L18D and slide L16B into L18A and L18B, then assemble the door frames using connector A28, as shown in the sketches below.





First the glazing panels should be loosely retained by the bar capping profiles L21C and L21D. Next tap the bar capping gently into position with a rubber mallet, then fix the bar capping securely with Z22 screws.





Slide 2xS12 into L18D, positioned 100mm away from each edge.
Secure S12 using M06 bolts, then rotate the wheels
to ensure free movement.







$a = b$




Expansion bolt
in concrete


It is essential the dimensions $a + b$ are the same to ensure the base is square.



$a = b$




Steel pegs in soil



Support at the corners only is inadequate.




GM34304



产品型号 代码	GM34304	GM34306	GM34308	GM34310	GM34312	etc.
$W_{(mm)}$	1910.7	1910.7	1910.7	1910.7	1910.7	
$L_{(mm)}$	2567.4	3802.4	5037.4	6272.4	7507.4	
$a=b_{(mm)}$	3200.4	4255.5	5387.6	6557	7746.7	
$a_1=b_1_{(mm)}$	3098.5	4124.9	5227.6	6367.1	7526.6	

- * W = Outer Width of Base Profiles
- * L = Outer Length of Base Profiles
- * $a=b$ = Outer Diagonal of Base Profiles
- * $a_1=b_1$ = Inner Diagonal of Base Profiles

GM34306















GM34306

* The basic model, GM34304, can be easily extended by adding '2 Section Assembly' each time for a longer size.

Attention:


the following steps are assembly example for GM34306 (GM34304 + one EXT.2 Sections). If you only buy the basic GM34304, there will be only L08C, without L08A. If your greenhouse consists of more than one extension module, then you will have more D24 joining plates to join the L08C and A's.

PART	NO	QTY
	L08A	2
	L08B	1
	L08C	2
	L10	1
	D07	17
	D24	2
	J11	4
	S08 M8X60	17
	S11 M6X20	4
	S14 M6X10	8
	M03 M6	12













Assemble L08A & A28 through D24, then tighten them with bolts and nuts.

First lay out the cills, connectors and anchor brackets approximately in place.














* It is essential that the L10 door cill is flat and level to ensure the smooth operation of the door




PART	NO	QTY
	L01A	2
	L01B	2
	L03C	1
	L03D	1
	L05A	2
	S14 M6X10	14
	M03 M6	14

Install the corner posts as shown and secure with the nuts & bolts provided.





PART	NO	QTY
	L01C	1
	L01D	1
	A26	3
	D17	3
	S14 M6X10	14
	M03 M6	14




Install L01C and L01D using connector A26 and part D17,
then tighten them with the nuts and bolts provided.

1











2



3

Connect L01B to L01D and L01A to L01C using connector A26 and part D17,
then tighten them with the nuts and bolts provided.















PART	NO	QTY
	L04A	3
	L05B	1
	L13	1
	S14 M6X10	8
	M03 M6	8

Install L13 horizontal braces in the rear wall.






Then install L04A & L05B with the nuts & bolts provided.







Remember to bolt the L05B brace in place when installing L04A.




PART	NO	QTY
	L03E	1
	L03F	1
	L04A	2
	L05A	2
	L23	1
	S14	13
	M6X10	
	M03	
	M03	10
	M6	

Install the door framing and bracing.




PART	NO	QTY
	L01C	1
	L01D	1
	A26	3
	D17	3
	S14 M6X10	16
	M03 M6	16


* During construction please ensure you temporarily support the front and rear wall framing until the structure is complete.



Install L01C and L01D using connector A26 and part D17, then tighten them with the nuts and bolts provided.




Connect L01B to L01D and L01A to L01C using connector A26 and part D17, then tighten them with the nuts and bolts provided.




Attention:

If you only buy the basic GM34304, there will be only L06B, without L06. If your greenhouse consists of more than one extension module, then you will have more L27 & L06 to extend.




Insert half part of L27 into L06, leaving 250mm length of L27. Then secure L27 and L06 with Z24.



PART	NO	QTY
	L06	1
	L06B	1
	L27	1
	D26	1
	D27	1
	Z22 Ø4X16	2
	Z24 M5X25	2
	S14 M6X10	4
	M03 M6	4

Insert another end of L27 into L06B, and ensure the junction works properly. Then secure them with Z24.




Assemble L06B & L06 through D27 with bolts and nuts.


Put D26 on the junction of L06B & L06, then drill the holes on L06B & L06 through the holes of D26, Dia.3.2mm.

Tighten D26 with Z22.


Please follow these steps if your order includes decorative crestring.





PART	NO	QTY
	L26A	5
	B01	18
	B02	12
	B03	10
	Z08 M4.2X16	4



Cut off 56mm from two profiles, L26, near to D26, and then install all L26 onto L06A & L06, making sure L26 matches the lengths of L06A & L06 (See Fig. above).




Drill one hole on both sides of L26, Dia.3.2mm, 150mm from centre of each L26, through L06A & L06, and then tighten them with Z22 (see Fig. above).



Slide B01, B02 and B03 into each side of L26 in the correct order. Use a rubber mallet if needed.




Attention:

If you only buy the basic GM34304, there will be only L07B, without L07. If your greenhouse consists of more than one extension module, then you will have more L07 to extend.




PART	NO	QTY
	L07	2
	L07B	2
	D25	2
	D27	2
	S14 M6X10	24
	M03 M6	24







Install the ridge section with two nuts and bolts at each end.




* When installing the L22Cs before tightening the nuts and bolts, push up from under the ridge near the join to ensure the entire ridge is straight.



PART	NO	QTY
	L02A	8
	L03A	2
	L03B	2
	L22C	6
	S14 M6X10	54
	M03 M6	54

















* Also ensure the eave profiles are running true and straight from end to end before tightening the L22Cs at the sides. You can also loosen these to make adjustments later.










Install L02A, ensuring that you loosely insert 2 extra bolts in the channel, which are needed later to fix the bracing.

Install horizontal & diagonal braces as shown to both sides of the greenhouse, ensuring that you loosely insert 1 extra bolt in the channel, which is needed later to fix the bracing L22A & L22D



PART	NO	QTY
	L02B	8
	L05C	12
	L22A	2
	L22D	2
	S14 M6X10	74
	M03 M6	74







Install L02B, ensuring that you insert 3 extra bolts in the channel, which are needed later to fix the bracing.

PART	NO	QTY
	L04A	4
	L05D	6
	L22	12
	A03	4
	S14 M6X10	52
	S11 M6X20	8
	M03 M6	60











Install the L04A vent frame profile and the A03 handle frame profile. Handle frame A03 is not required if auto openers are installed. Install L04A and L05D at the same time. When installing L05D ensure that you leave one bolt in the bolt channel for L22. Install the L22 ridge and eaves struts. The L22 struts are fitted horizontally at the ridge and diagonally at the eaves.







Ensure 2 bolts are inserted in the bolt channel for the A03 handle.


















The frame is now complete. Once you start the glazing ensure that you complete it. Do not leave the greenhouse half glazed as this may cause damage.





PART	NO	QTY
	L11A	2
	L11B	2
	L11C	3
	L12C	1
	L12D	1
	L12G	3
	Y1	1
	Y2	3
	Y3	1
	Y4	1







First the glazing panels should be loosely retained by the bar capping profiles as shown in the detail drawings. Next tap the bar capping gently into position with a rubber mallet.








PART	NO	QTY
	L11A	2
	L11B	2
	L11D	2
	L11E	1
	L12C	1
	L12D	1
	L12G	2
	Y1	1
	Y2	2
	Y4	1
	Y5	1






First the glazing panels should be loosely retained by the bar capping profiles as shown in the detail drawings. Next tap the bar capping gently into position with a rubber mallet.






PART	NO	QTY
	L11A	4
	L11C	12
	L12A	10
	Y6	12





1








2








Slide all Y6 glazing panels into place. The top of the panels should be pushed up behind the gutter profile, then pushed in against the base profile as shown in the detail drawings. The panels should be loosely retained by the glazing bar capping L11A, L11C and L12A then tap the bar capping gently into the channels of each frame profile with a rubber mallet.


PART	NO	QTY
	Y7	8
	Y9	4






PART	NO	QTY
	L09	2
	L09B	2
	L11B	4
	L12B	10
	L12G	4


1











2



3




Tap all of the bar capping into the channels of each frame profile with a rubber mallet as shown in the detail drawings.







Fix every bar capping profile securely in position using Z22 screws as shown in the detail drawings.

* Be careful not to over tighten but ensure the screws are securely fixed. Ensure the bar capping profiles are pushed firmly against the panel before installing the screws.



PART	NO	QTY
	L14	1
	WINDOWS	4
	Z02 Ø4X16D	8
	M03 M6	3


PART	NO	QTY
	AUTO OPENER	4
	D28	4
	S11 M6X20	8
	M03 M6	8



Manual Opener




*Ensure the manual vent is closed as shown.















Automatic Opener





Slide L15A along the groove in the L06 ridge and fix it in the correct position using Z02 screws.





Rotate H18, the roller wheels, to adjust the height of the door so it does not bind or rub on the bottom track.



PART	NO	QTY
	L30	4
	J09	2
	J10R/L	2/2
	J12R/L	1/1
	J94	4
	J93	4
	J92	4
	Z02 Ø4X16D	18
	Z22 Ø4X16	4



Downpipe Assembly



If you wish to eliminate leaks use glue when fixing the downpipe bends (not provided).

Drill a hole in L01A and L01B, approximately 3mm diameter and 700mm up from the bottom. Fix the J92 downpipe bracket with Z22 screws and then clip the L30 downpipe into the J92 bracket.